

Warning Only qualified service personnel should install and service this product to avoid injury. Observe all ESD procedures during installation to avoid damaging the equipment.

NOTE Refer to the Unpacking List for the exact amount of items included in the package.


1 Installing hard drives

Warning DO NOT remove more than one hard disk drive trays from the enclosure at the same time.

1.1 Installing a 2.5 inch HDD into the tray


1.1.1. Removing the HDD tray

Press on the release button to open the bezel and gently pull the hard drive tray out of the enclosure.




1.1.2. Attaching the HDD

1. Place the hard drive into the drive tray. The interface connector should face the open side of the tray, with the label of the hard drive facing up.




2. Secure the HDD onto the tray according to the following screw positions.



1.2 Installing a 3.5 inch HDD into the tray


1.2.1. Removing the HDD tray

Press the release button to open the bezel and gently pull the HDD tray out of the enclosure.




1.2.2. Attaching the HDD

1. The interface connector should face the open side of the tray, while the label side should face up.




2. Secure the drive by fastening four (4) of the supplied screws.

a. Locates the screws of 3.5" SATA HDD




b. Screw locations for 2.5" HDD in 3.5" tray

- 2.5 inch SATA HDD / SSD (with MUX board)
- MUX board screw locations




1.3 Inserting and securing the HDD tray

1. Insert with the tray bezel open.




2. Once fully inserted, close the bezel till it's snapped.



2 Powering up


2.1 Connecting the power cord

Connect the included power cord(s) to the power socket(s) (shown in blue) of the system.



2.2 Powering up the system

1. Power up the networking devices.
2. Power up the system by pressing the main power switch located on the rear panel.
3. Power up the application servers.




2.3 Verifying the status LEDs (front of enclosure)

Observe the front of the enclosure. If the LED indicators show different status than described below, or if you hear an audible alarm, contact customer support.

2.3.1 LED panel

1U model



Item	Description
1	Mute / Service button
2	Power: ON
3	Cooling: ON
4	Thermal: ON
5	System: ON


2U model



Item	Description
1	Service: OFF
2	Power: ON
3	Cooling: ON
4	Thermal: ON
5	System: ON
6	Mute / Service button

2.3.2 Drive tray status LED

1. Drive Activity LED:
Flashing = R/W activity (**Blue**)
2. Power Status LED:
On (Green)
Failure (Red)




2.4 Verifying the status LEDs (rear of enclosure)

Observe the rear of the enclosure. If the LED indicators show different status than described below, or if you hear an audible alarm, contact customer support.


2.4.1 Controller LEDs:

Item	Description
1	Ctrl Status LED: On (green)
2	Cache Dirty LED: Off
3	Host Busy LED: Off



2.4.2 Verifying power status


1. One power status LED is located on each PSU itself.
A **green** LED indicates a working power supply.
Amber indicates a faulty power supply.
2. The main power status LED is located on the front LED panel (please see 2.3.1).




3 Interfaces

Interface overview

Managing and monitoring the system is available through two types of interfaces. Refer to the sample figures on the right for controller host ports and management interfaces.



- Host PC (in-band connection):
Users will access the system from the host servers through the host links.
- Ethernet jointing (out-of-band connection):
You can access the system from a remotely connected computer using Ethernet cables. Connect the system with your PC by jointing, and the PC will scan to search for the system IP automatically. After retrieving the system IP, connect the system(s) to EonOne.



- Serial port:
You can access the system from a directly connected computer through the RS-232C port. The serial cable is user-supplied.

Item	Description
Baud rate	38400
Data bit	8 bit
Parity	none
Stop bit	1
Flow control	hardware

4 Accessing management tools

You may control the system using the firmware menu (through RS-232C interface) or the EonOne GUI software (through the Ethernet or host PC interface). For more tools and their details, refer to the manuals in the CD-ROM.

Firmware menu:

1. Open a terminal emulation software such as VT-100 on your PC.
2. Configure the serial port as shown in the previous section and connect the system. The main firmware menu will appear.
3. Here you can check the current IP settings.

EonOne:

1. Connect the system to a remote computer through the Ethernet port or to a host PC through the host links.
2. Install the EonOne software suite, included in the CD-ROM, into your computer.
3. Start the EonOne software. Type in user name (default: **admin**) and password (default: **admin**) to log-in as administrator.



4. Add the system to the **Device List**.
5. Click the **Gear Icon** right, top to configure the system.
6. To activate a license click on **System**.
 - 6a. Click on **License Management** and generate a License Application File by clicking on **Generate License Apply File**. Save the file.
 - 6b. Visit <http://www.infortrend.com/license> to register by use of the License Application File. The **License Number** is attached in the software license envelop.
 - 6c. Type in the **License Number**. Download the **License Key File** and upload it to EonOne to activate the license.

